1.12 Python operations MySQL database

MySQL Connector/Python Developer Guide: https://dev.mysql.com/doc/connector-python/en/

> 安裝 mysql.connector 模組

Install corresponding Python 3 module on linux:

```
# sudo apt-get install python3-mysql.connector
```

Install corresponding Python 2 module on linux:

```
# sudo apt-get install python-mysql.connector
```


Install corresponding Python 3 module on windows

```
# pip install mysql-connector-python
```

https://pypi.org/project/mysql-connector-python/

> Python MySQL Connect Database

建立「mydatabase 資料庫」,建立「customers」,細節如下:



Try connecting to the database "mydatabase":

```
#!/usr/bin/python
# -*- coding: utf-8 -*
import mysql.connector

mydb = mysql.connector.connect(
   host="localhost",
```

```
user="root",

passwd="1234",

database="mydatabase"
)

mydb.close()
```

範例: operation_mysql1.py

▶ 插入資料(insert)

```
#!/usr/bin/python
# -*- coding: utf-8 -*
import mysql.connector
mydb = mysql.connector.connect(
 host="localhost",
 user="root",
 passwd="1234",
database="mydatabase"
)
mycursor = mydb.cursor()
sql = "INSERT INTO customers (name, address) VALUES (%s, %s)"
val = ("John", "Highway 21")
mycursor.execute(sql, val)
```

```
#提交
mydb.commit()
print(mycursor.rowcount, "record inserted.")
```

範例: operation_mysql2.py

```
#!/usr/bin/python
# -*- coding: utf-8 -*
import mysql.connector
from mysql.connector import errorcode
# Obtain connection string information from the portal
config = {
'host':'localhost',
'user':'root',
'password':'1234',
'database':'mydatabase'
}
# Construct connection string
try:
conn = mysql.connector.connect(**config)
  print("Connection established")
```

```
except mysql.connector.Error as err:
if err.errno == errorcode.ER_ACCESS_DENIED_ERROR:
print("Something is wrong with the user name or password")
elif err.errno == errorcode.ER_BAD_DB_ERROR:
print("Database does not exist")
else:
print(err)
else:
cursor = conn.cursor()
# Insert some data into table
cursor.execute("INSERT INTO inventory (name, quantity) VALUES (%s, %s);",
("banana", 150))
print("Inserted",cursor.rowcount,"row(s) of data.")
# Cleanup
conn.commit()
cursor.close()
conn.close()
print("Done.")
```

範例: operation_mysql3.py

▶ 讀取資料 (read)

#!/usr/bin/python

```
# -*- coding: utf-8 -*
import mysql.connector
from mysql.connector import errorcode
# Obtain connection string information from the portal
config = {
'host':'localhost',
'user':'root',
'password':'1234',
'database':'mydatabase'
}
# Construct connection string
try:
conn = mysql.connector.connect(**config)
print("Connection established")
except mysql.connector.Error as err:
if err.errno == errorcode.ER ACCESS DENIED ERROR:
   print("Something is wrong with the user name or password")
elif err.errno == errorcode.ER_BAD_DB_ERROR:
print("Database does not exist")
else:
print(err)
else:
 cursor = conn.cursor()
```

```
# Read data
cursor.execute("SELECT * FROM inventory;")
rows = cursor.fetchall()
print("Read",cursor.rowcount,"row(s) of data.")
print type(rows)
# Print all rows
for row in rows:
print("Data row = (%s, %s, %s)" %(str(row[0]), str(row[1]),
str(row[2])))
# Cleanup
cursor.close()
conn.close()
print("Done.")
```

範例: operation_mysql4.py

> 更新資料(update)

```
#!/usr/bin/python
# -*- coding: utf-8 -*
import mysql.connector
from mysql.connector import errorcode
```

```
# Obtain connection string information from the portal
config = {
'host':'localhost',
'user':'root',
'password':'1234',
'database':'mydatabase'
}
# Construct connection string
try:
conn = mysql.connector.connect(**config)
print("Connection established")
except mysql.connector.Error as err:
if err.errno == errorcode.ER ACCESS DENIED ERROR:
print("Something is wrong with the user name or password")
elif err.errno == errorcode.ER BAD DB ERROR:
print("Database does not exist")
else:
print(err)
else:
cursor = conn.cursor()
 # Update a data row in the table
cursor.execute("UPDATE inventory SET quantity = %s WHERE name
= %s;", (200, "banana"))
```

```
print("Updated",cursor.rowcount,"row(s) of data.")

# Cleanup
conn.commit()
cursor.close()
conn.close()
print("Done.")
```

範例: operation_mysql5.py

▶ 删除資料(delete)

```
#!/usr/bin/python
# -*- coding: utf-8 -*

import mysql.connector
from mysql.connector import errorcode

# Obtain connection string information from the portal
config = {
    'host':'localhost',
    'user':'root',
    'password':'1234',
    'database':'mydatabase'
}

# Construct connection string
```

```
try:
conn = mysql.connector.connect(**config)
print("Connection established.")
except mysql.connector.Error as err:
if err.errno == errorcode.ER ACCESS DENIED ERROR:
print("Something is wrong with the user name or password.")
elif err.errno == errorcode.ER BAD DB ERROR:
print("Database does not exist.")
else:
print(err)
else:
 cursor = conn.cursor()
# Delete a data row in the table
cursor.execute("DELETE FROM inventory WHERE name=%(param1)s;",
{'param1':"orange"})
print("DELETE FROM inventory WHERE name=%s;", "'apple')
cursor.execute("DELETE FROM inventory WHERE name=%s;",
"'apple'")
print("Deleted",cursor.rowcount,"row(s) of data.")
# Cleanup
conn.commit()
cursor.close()
conn.close()
```

print("Done.")

範例: operation_mysql6.py

文獻:

https://docs.microsoft.com/zh-tw/azure/mysql/connect-python

> 小專案

目標:將溫度 DS18B20 溫度感測器,傳入本機資料庫

1、建立資料庫

IOT(utf8_unicode_ci)

1

temperature_DB


2

26.6

ID		userid	temperature	datetime
INT		INT	float	datetime
A_I				
Primar	y Key			
1	1	25.2		2015/11/28 19:00:00



2015/11/28 21:00:00



2、撰寫 python 程式

範例: upload_temperature_mysql.py